

200 User Manual

COB PAR Light



200W LED COB PAR light



Please read carefully before operating the led light.

“MENU”: press this button to working mode;

“UP” “DOWN”: press this button to change value;

“ENTER”: press this button to confirm.

● LED Display Function

(choose working mode, then press “ENTER”)

No.	Display	Function
1	A001	DMX address no.,(A001-512) Press “UP” “DOWN” to change the value
2	1CH-2CH-3CH	4 kinds of DMX Mode
3	CP99	Change automatically (CP01-99) Press “UP” “DOWN” to control changing speed
4	St99	Strobe(ST01-99) Press “UP” “DOWN” to control strobe speed
5	bE01- BE02	2 kinds of Sound mode
6	o255	Warm white color (W000-255) Press “UP” “DOWN” to control brightness
7	-on- / -oFF	Led display ON/ OFF

☆ DMX512 Instruction (A2ch)

Channel	Value	Function
1	0-255	Warm white dimmer
2	0-255	strobe

☆ DMX512 Instruction (b2ch)

Channel	Value	Function
1	0-255	Warm white dimmer
2	0-255	0-20 no function; 21-200 strobe/ strobe speed; 201-240 sound mode 1; 241—255 sound mode 2

☆ DMX512 Instruction (-1ch)

Channel	Value	Function
1	0-255	Warm white dimmer

☆ DMX512 Instruction (-3ch)

Channel	Value	Function
1	0-255	Warm white dimmer
2	0-255	strobe
3	0-255	0-20 no function; 21-255 change automatically/ changing speed;

● SPECIFICATIONS:

Voltage: AC90-240V,50/ 60HZ

Power: 200w

Light source: 200w led warm white

Angle: 60°

Strobe:1-10times/ second

Mode: DMX512/ Master-slave

DMX Channel: 2/2/1/3 Channel

Size: 25*22*28cm

Weight: 5kg