



FLAMY100X

MACCHINA FUOCO SINGOLA FIAMMA 100W DMX



USER MANUAL

www.timpani.it



Introduction

Congratulations on the purchase of flame machine. We are confident you will enjoy many trouble free hours with this unit. To assist with the care and use of the product we have prepared this short guide.

1. Open the package, make sure the whole appearance and accessories is intact.
2. This machine belongs to the open fire products. Therefore, it shall be installed in the place with 8m diameter 3m height and without any flammable materials.
3. Put the machine in the proper place with the spout upward.
4. Flame liquid bottle placed in the body (using our environmentally friendly flame liquid can extend machine life and reduce the failure rate).
5. Then choose the control mode.

6. DMX512 address code:

(1) Corresponding relationship of toggle switch address code number and DMX512 controller address number: 1 2 3 4 5 6 7 8 of toggle switch address code corresponding to 1 2 4 16 32 64 128 of DMX512 address code.

(2) 2 channels of DMX signal control: put the first fader, it will show fireball; put the first and second fader at the same time, it will show pillars of fire. This machine has continuous fire-breathing for 3 seconds then power off automatically and turn off flame protection function.

7. Continuing fire-breathing time, please do not over 3 seconds.

Turn up - , mean to
connect MDX

Turn middle, mean
stop

Turn down =, it's
spray fire directly



8. Technical parameters:

Voltage: AC220V 50/60Hz

Power: 100W

Flame height :1-2m

Coverage: 1 square meter

Control : DMX + Manual directly