

CONFY700

Electricity-driven Confetti Machine

USER MANUAL

- **1.** Before use, position the nozzles in the direction to which the launch should be carried out.
- **2.** Connect the machine to the power source.
- **3.** Manual control: turn on the power switch on the control panel. When the "POWER" is red and you hear the sound, open the lid on the machine and put confetti inside. The confetti will be launched at a height of 6-7 meters. To stop the throwing of the confetti, operate unplug the machine from the power source
- **4.** Remote control: turn on the switch and press the buttons on the remote control to send the signals to the machine.

Technology Parameter	
Voltage	AC110V~120V 50Hz
Power	1000W
Control	remote control and Power Supply
Height of Ejection	6-7M
Size (mm)	800x450x700 mm (LxWxH)
Weight (Kg)	33Kg







Timpani S.r.l. Via Idiomi 1/42 - 20090 Assago MI



timpani.it



+39 051.356956



+39 342.3929868



info@timpani.it

