

BUBBLY100X


Roller Bubble Machine

User Manual

1. put the machine in the appropriate position, insert about 2 liters of liquid bubbles and connect the power supply.
2. continuous button ▲ : amount of bubbles from a few to many
continuous button ▼ : number of bubbles from many to few until the stop

This machine works with DMX 512 or remote control. Use the button ■ to change control type.

For the remote control functions, look at the following diagram.





Technology Parameter	
Voltage	AC220V~240V 50Hz
Power	150W
container	2l
Size (mm)	450 x420 x230 mm (LxWxH)
Weight (Kg)	6



Timpani S.r.l.
Via Idiomi 1/42 - 20090 Assago MI



timpani.it



+39 051.356956



+39 342.3929868



info@timpani.it